


CUCINA
by *Giani*

IM-GCSD80A090913



Power Juicer

Instruction Manual

Model Reference: GCSD80A

Important Safety Information

Read all of the instructions before using this appliance and keep safe for future reference.

When using electrical appliances, basic precautions should always be followed, including the following:

- This appliance is for domestic use only. Do not use outdoors or on wet surfaces.
- Do not handle the plug or appliance with wet hands.
- Do not immerse the main body in water.
- Do not touch any moving parts.
- Do not insert objects other than food into the juicer when operating. If food becomes lodged or blocked, switch off the appliance and unplug from the mains before attempting to clean.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be performed by children without supervision.
- This product is not a toy.
- Do not use the appliance if any parts appear to be faulty, missing or damaged.
- Do not leave the appliance unattended when connected to the mains supply.
- Always unplug from the mains supply before carrying out any cleaning, performing user maintenance or changing accessories.
- Switch off the appliance by the power switch before removing the plug from the mains supply.
- Keep hair, loose clothing, fingers and all parts of the body away from any openings of the appliance.
- Do not use the appliance if it has been dropped or damaged in any way.
- Check to ensure that the electricity supply matches that shown on the rating plate.
- Only use the attachments/accessories supplied with the product or recommended by Giani.
- If the supply cord is damaged, it must be replaced by a qualified service agent in order to avoid a hazard.
- Only use this appliance for its intended domestic use. Giani Ltd will not accept any liability if the appliance is subject to improper use, or failure to comply with these instructions.
- The parts and accessories are not suitable for cleaning in a dishwasher.
- Do not run the product when it is empty.



The maximum operating time is 3 minutes. Do not exceed this time or it will damage the motor. Allow to cool down for 20 minutes in between uses.

Thank you for choosing the JD Williams Slow Juicer.

Remove all packaging material. You may wish to keep the packaging for future use or storage for your appliance. Alternatively, dispose of accordingly.

Index

Important Safety Information.....	2
Product Overview.....	3
Using the Aparatus.....	3
Preparing Fruits & Vegetables for Juicing.....	3
Use.....	4
Storage.....	4
Cleaning.....	4
Aftersales Support.....	6

Product Overview

1. Food Plunger
2. Fruit Pulp Holder
3. Motor Housing
4. Locking Arm
5. Juice Spout
6. Juicer Housing
7. Juicing Blade
8. Feed Chute
9. Lid
10. Power Switch



Prior to First Use

Before using for the first time, or after prolonged storage without use, wash any parts that will come into contact with food.

Using the Apparatus

Assembly before use:

- Place the motor housing (3) on a flat surface, eg: a kitchen counter, and make sure it is standing firmly on the four suckers underneath
- Place the juicer housing (6) on the motor section so that the juice spout (5) fits in the slot on the side of the motor housing.
- Push the fruit pulp holder (2) up under the drain edge on the base so that it locks onto the foot of the motor unit tightly.
- Carefully lock the juicing blade (7) into the juicer housing.
- Be careful not to touch the sharp parts of the juicer blade.
- Make sure that the juicer blade sits properly on its base and that it rotates evenly.
- Place the lid (9) on the appliance so that it covers both the fruit pulp holder and the juicing blade. Make sure that the lid fits tightly onto the base.
- Turn the locking arm (4) to the vertical position and make sure that it engages the lid and locks it. The locking arm makes a clicking sound when it is done correctly.
- Place a glass, bowl or other suitable container under the spout.
- The apparatus is now ready for use.

Preparing Fruits & Vegetables for Juicing

- Always wash fruits and vegetables thoroughly before juicing.
- It is not necessary to remove small seeds, pips or thin peels before using the appliance.
- Fruits with thick peels such as oranges and lemons should be peeled before juicing. It is particularly important to remove all the peel, as even a small amount can cause an unpleasant taste to the juice.
- It is also necessary to remove large pips/stones (such as plum and apricot pips/stones) to avoid damaging the appliance.
- Large fruits and vegetables should be cut into pieces that can fit into the feed chute (8).

Use

- Start the appliance by turning the control dial to position “1” (low speed) or position “2” (high speed).
- The low speed setting is suitable for juicing soft fruits and vegetables.
- The high speed setting is suitable for juicing harder fruits and vegetables.
- Feed the selected fruits and/or vegetables into the appliance through the funnel a little at a time, pushing them down using the food plunger (1).
- Make sure that you turn the food plunger so that the groove in the food plunger fits into the feed chute properly.
- Long vegetables such as carrots should be fed into the feed chute point end first.
- Press the fruit and/or vegetables gently with the food plunger. Too much pressure reduces the amount of juice extracted and can damage the appliance.
- Stop the appliance before removing the food plunger to add more fruit/vegetables in order to avoid any splashes.
- Keep an eye on the fruit pulp holder and stop juicing before the holder becomes too full.
- Always turn off the power by turning the control dial to “0” position before taking off the lid.

CAUTION: Do not leave the appliance running for more than 3 minutes at a time. If the appliance has been running for 3 minutes, allow it to cool down for 20 minutes before you use it again.

Tip

- If you line the fruit pulp holder with a plastic bag before using the appliance, it will be easier to clean.
- Use fresh fruits and vegetables - they contain the most juice
- Good foods for juicing include: pineapple, apples, cucumbers, celery, carrots, spinach, melons, tomatoes and most citrus fruits.
- The various varieties of apple yield juice with different flavours and consistency. Experiment with different combinations.
- Leafy green vegetables such as cabbage and spinach can be juiced. Roll the leaves into cylinders of an appropriate size before feeding them into the feed chute.
- Fibrous fruits and vegetables as well as those with very firm flesh such as bananas, mango's papayas and avocados are not well-suited to juicing, as the result is often mashed fruit instead of juice.
- All types of juice should be consumed right after juicing, as fresh juice quickly loses important nutrients when exposed to the oxygen in the air. The taste can also be affected.
- Pure apple juice turns brown quickly when exposed to air. To prevent it discolouring, serve the apple juice immediately after juicing or add a little lemon juice.
- Remember that fruit pulp can be used in cakes, vegetable lasagne, muffins etc.

Storage

- Ensure the appliance is clean and dry before storing
- The appliance contains sharp parts - keep out of reach from children

Cleaning

- Remove the plug from the wall socket and allow the apparatus to cool down before cleaning.
- The best way to clean the motor housing is with a damp cloth and, if necessary, a little detergent. Do NOT immerse the motor section in any form of liquid.
- The centrifuge bowl, fruit pulp holder, base and all other detachable parts can be washed by hand or in a dishwasher.

- Be careful not to touch the sharp parts in the bottom of the centrifuge bowl.
- Do not use any kind of strong or abrasive cleaning agent on the appliance or its accessories. Never use a scouring sponge or similar to clean it, as the surface may become damaged.
- Allow all parts of the appliance to dry completely before reassembling it after cleaning.

After Sales Support

If you need help using your Power Juicer, please contact Giani Ltd:

Tel: 0161 480 6204

Email: info@gianiuk.co.uk

Website: www.gianiuk.co.uk
(replacement instruction manuals are available to download)



CUCINA
by *Giani*

Giani Limited - SK2 6RH